

### Manual Pro Series Dimensions Table - EN Type

Model Number	Diag. Size	Aspect Ratio	Screen Material	Case Color	Gain	Case Length (A)	View Width (A1)	Case length (w/out hanging ring) (A2)	Distance Between hanging rings (A3)	Screen Width (A4)	Weight Bar Length (A5)	L / R black masking border (A6)	Overall Height (B)	View Height (B1)	Overall H (Without hanging ring) (B2)	Screen Height (B3)	Top black masking border (B4)	Bottom black border (B5)	Case Width (C)	Case Height (C1)	Case H (w/out hanging ring) (C2)	Distance screen material to wall (C3)	Weight Bar Diameter (C4)
Units: inch																							
AVM100UH	100"	16:9	MaxWhite® 2	Black	1.1	93.5	87.2	93.1	92.8	90.2	92.8	1.5	62.6	49.0	57.4	60.6	6.0	2.4	2.7	4.0	3.2	0.7	0.9
AVM120UH	120"	16:9	MaxWhite® 2	Black	1.1	110.9	104.6	110.6	110.2	107.6	110.6	1.5	72.4	58.8	67.2	70.4	6.0	2.4	2.7	4.0	3.2	0.7	0.9
AVM120XH	120"	16:9	MaxWhite® 2	White	1.1	110.9	104.6	110.6	110.2	107.6	110.6	1.5	72.4	58.8	67.2	70.4	6.0	2.4	2.7	4.0	3.2	0.7	0.9
Unit: mm																							
AVM100UH	100"	16:9	MaxWhite® 2	Black	1.1	2374	2214	2366	2356	2290	2358	38	1590	1245	1458	1540	152	60	69	102	82	17	23
AVM120UH	120"	16:9	MaxWhite® 2	Black	1.1	2817	2657	2809	2799	2733	2809	38	1839	1494	1707	1789	152	60	69	102	82	17	23
AVM120XH	120"	16:9	MaxWhite® 2	White	1.1	2817	2657	2809	2799	2733	2809	38	1839	1494	1707	1789	152	60	69	102	82	17	23

The listed measurements are for general reference only. Please contact Elite ProAV to verify product design and dimensions before attempting to integrate its products with any structural or furniture modification. Although a manufacturer may offer product advice, it may be taken or disregarded at the integrator's discretion. Elite ProAV will not be held responsible or be otherwise liable for faulty installations.

